

110.00 m m



Wireless keyboard with device holder

User Manual

Dimensions	291 x 159 x 16mm
Weight	470 grams
Power supply	180mAh Li-battery
Operating Frequency	2.402-2.480GHz
Connection via	Bluetooth 3.0
Pairing name	Silvergear Keyboard 1082
Operating range	Up to 10 meters
Runtime	Up to 100 hours
Standby time	30 days
Charge time	2-3 hours
Compatible	Android, iOS, Windows
Charging cable type	Micro USB

1.Led Display

- Power: The blue indicator lights up 2 seconds when the keyboard is turned on.
- Low power: The blue indicator flashes rapidly when the power is low.

2.System requirements

- iOS all versions.
- Android 3.0 and above.
- Windows Mobile 5.0 and above.
- Bluetooth-enabled PC/Laptop with Windows XP 10 or above.
- Bluetooth-enabled iMac/MacBook with Mac OS X 10.2.8 or above
(this keyboard may not be totally compatible with all the MacOS devices).

3.Pairing keyboard methods

Pairing with an iPad/iPhone

- Step 1: Slide the power switch to on.
Step 2: Press "Fn+C". The Bluetooth indicator flashes blue.
Step 3: Select on the iPad/iPhone: Setting > Bluetooth > On.
Step 4: The iPad/iPhone displays "Silvergear Keyboard 1082" as an available device.
Step 5: Select "Silvergear Keyboard 1082".

Pairing with Tablets, Smartphones, Laptop and Desktop computers

- Step 1: Slide the power switch to on.
Step 2: Press "Fn+C". The Bluetooth indicator flashes blue.
Step 3: Go to the Bluetooth settings menu of your device to activate Bluetooth and search for "Silvergear Keyboard 1082".
Step 4: The tablet, smartphone, laptop or desktop displays "Silvergear Keyboard 1082" as an available device.
Step 5: Once the Bluetooth keyboard has successfully been connected to your device, the Bluetooth indicator will turn off

110*150mm

105克铜版纸双面单色印刷

Note:

- Only one device can be actively paired at the same time.
- After pairing for the first time, your device will connect to the keyboard automatically when switching on the keyboard.
- In case of connection failure, delete the pairing record from your device and try the above pairing procedures again.

Power saving mode

The keyboard will enter into the power saving mode after not being in use for 15 minutes. To activate the keyboard, press any key and wait 3 seconds.

Keys	on Android	on Windows	on IOS	Fn + for all w/o
	Return	Return	Return	ESC
	Home	Browser	Home	F1
	Search	Search	Search	F2
	Select	Select	Select	F3
	Copy	Copy	Copy	F4
	Stick	Stick	Stick	F5
	Cut	Cut	Cut	F6
	Pre-Track	Pre-Track	Pre-Track	F7
	Play/Pause	Play/Pause	Play/Pause	F8
	Next	Next	Next	F9
	Volume down	Volume down	Volume down	F10
	Volume up	Volume up	Volume up	F11
	Screen Lock	Screen Lock	Screen Lock	F12

Note:

Press "Fn" and "Q" (Android), "W" (Windows) or "E" (iOS) keys together to switch between Android, Windows or iOS systems after connecting with a corresponding device. Otherwise the keyboard's function key will only be partial valid. For iOS, the Language Exchange function does not work below version 9.2. Press "command+Space" to switch languages.

Important guidelines:

- Read the user manual carefully and keep it for reference.
- Use this product only as described in this user manual.
- If the instructions are not followed, the manufacturer may not be held responsible for damage that may result from incorrect use of this product.
- Let repairs be done by a qualified mechanic. Never try to repair the product yourself.
- Do not place heavy objects on the keyboard.
- Keep the product away from water, oil, chemicals and organic liquids.
- Clean the product by lightly rubbing it with a slightly damp cloth.

GUIDELINES FOR PROTECTION OF THE ENVIRONMENT
(WEEE , directive on waste of electrical and electronic equipment)

Your product is designed and manufactured with high quality materials and components which can be recycled and reused. This appliance should not be put into the domestic Garbage at the end of its durability, but must be offered at a central point for the recycling of electric and electronic domestic appliances. This crossed-out wheele bin symbol on the Appliance, instruction manual and packaging puts your attention to this important issue. The materials used in this appliance can be recycling. By recycling used domestic appliances you contribute an important push to the protection of our environment. Ask your local authorities for information regarding the point of recollection.



Overschiestraat 63
1062 XD Amsterdam
The Netherlands
info@silvergear.eu

www.silvergear.eu

art. no.: 1082 batch no.: 19C52

